

MOUNTING INSTRUCTIONS FOR CX4 STORM TOP RAIL

The Top Rail Accessory Kit, part number E00268, contains one rail, three screws and two nuts. For proper installation you will need a 4mm (or 5/32") drill bit, a screwdriver and the multi-purpose tool included with your CX4 Storm carbine. An electric drill or driver will also be helpful for Step 5.

WARNING: Always be certain that the carbine is unloaded. Refer to the Load Check instructions on page 19 of the CX4 Storm Instruction Manual

Following the disassembly instructions in the CX4 Storm Instruction Manual (see pages 21 & 22), field strip the upper receiver to the level shown in Figure 13 of the manual.

Position the top rail on the upper receiver as indicated in Photograph 2.

Insert one of the three screws (they are identical) into the forward threaded seat near the front sight. See Photograph 3.

Tighten the screw down lightly until the screw head seats into the top rail and keeps it in position. Do not tighten down the screw. See Photograph 4.

The top rail will now act as a template to drill through the thin polymer membrane that covers the rear two holes. Using the 4mm (or 5/32") drill bit, gently drill through the material in the rearward hole (closest to the rear sight). If using an electric drill or driver, be careful - there is very little material and you will drill through it very easily. See Photograph 5.

Using the same methodology, drill through the center hole. Be careful not to drill into the underlying barrel. See Photograph 6.

Using the multi-purpose tool included with your CX4 Storm carbine, position one of the nuts on the tool as shown in Photograph 7.

Using the tool, guide the nut "over" the barrel and position it under the center hole. See Photograph 8. Ensure that it is located correctly by looking down through the top rail hole.

Thread one of the screws in manually until you are sure that it has threaded into the nut. Remove the tool. Using the screwdriver, tighten the screw down lightly. Do not tighten down the screw.

Position the last nut under the rearward hole as shown in Photograph 9 and tighten the last screw down lightly. All three screws should now be tightened down.

Reassemble the carbine following the assembly instructions in the CX4 Storm Instruction Manual (see page 23).

For a more permanent installation of the top rail, you may want to use low strength Loctite® #22 (purple) on the threads of the screws.



Beretta U.S.A. Corp - 17601 Beretta Drive - Accokeek, MD 20607, USA
For Parts, Service and Repairs, or product inquiries, please call (800) 636-3420